

SNA Sportmaster Maintenance Recommendations

- 1) **Yearly**, it is highly recommended that all bolts be checked to ensure they are tight. Areas to pay close attention to are as follows:
 - a) Backboard mounting bolts (directly behind rim)
 - b) V-brace mounting bolts (connected to upper corners of backboard)
 - c) Safety Padding bolts (do not over-tighten these bolts!)
 - d) Bolts connecting the footcups to the long lead screws (where you ratchet the footcups down at the front corners of goal)
- 2) **Yearly**, lubricate the lead screws to reduce wear on the threads.
- 3) If any height or level issues arise, loosen up the stop collars on the top of the lead screws, back them completely off, and use the ratchet to drive the lead screws far enough down to achieve the correct height and level. Afterward, replace the stop collars, screw them down firmly against the top front of the frame, and tighten them into place with allen wrench. If issues persist, contact SNA Service at (800)823-0182.

Suggestions For Each Use

- 1) **Make certain** that the Telescopic Rod Locking Pin is in place through the telescopic rod and the lead screws are completely ratcheted down before playing on the goal!
- 2) Always assist the goal up into its game position and down into its collapsed position. **Under no circumstances** allow the goal to collapse without slowing its descent, or damage could result to the goal!!!!

----Please feel free to direct any further questions to the SNA Service Department at (800)823-0182--

--