

SNA Sports Portable Basketball Maintenance Recommendations

- 1) **Yearly**, it is highly recommended that all bolts be checked to ensure they are tight. Areas to pay close attention to are as follows:
 - a) Backboard mounting bolts (directly behind rim)
 - b) V-arm mounting bolts (connected to upper corners of backboard)
 - c) Safety Padding bolts (do not over-tighten these bolts!) and hangers
 - d) Bolts connecting the sub-frame to the chrome struts (front inside corners of goal)
- 2) **Yearly**, check the bottom of the sub-frame bars to make certain the felt padding or rubber padding is still in place.
- 3) If any binding occurs between the struts and blocks preventing the sub-frame from moving smoothly, lubricate the struts and roller bearings at the top with lithium-based grease.
- 4) If any height or level issues arise, or if a goal is becoming difficult to raise or lower, please contact SNA Sports Service at (800)823-0182.

Suggestions For Each Use

- 1) **Make certain** that the Telescopic Rod Locking Pin is in place through the telescopic rod and the Fixation Knob is tight before playing on the goal on the "Made in Holland" models. On the "Made in the USA" models, make certain the black pull pin and deadlock turnbuckle are fully engaged. For added security, use a hitch pin through the telescopic rod in the middle hole.
- 2) Always assist the goal up into its game position and down into its collapsed position. **Under no circumstances** allow the goal to collapse without slowing its descent, or damage could result to the goal!!!!

---Please feel free to direct any further questions to the SNA Sports Service Department at (800)823-0182---